PR-12A
Operating Manual

www.enwsound.com

Safety Precautions

The installation of this speaker cabinet must be carried out by qualified personnel following the approved safety standards.

Do not attempt to clean the plastic enclosure with solvents or petrochemical based cleaners.

Do not place objects which are sources of heat on the speaker cabinet such as lighting equipment or smoke machines.

Do not expose the speaker cabinet to direct rain or stand in water. Liquid getting into the box will risk a short circuit and will be hazardous.

Do not stack the speaker cabinet in a manner that could cause injury should a cabinet become dislodge.

Additional precautions for Auto-amplified devices of the series.

Before installation, ensure that the voltage and frequency of power outlet match the power requirements of the loudspeaker.

Disconnect from main power before to make connections in the loudspeaker.

Make sure that the power-cord is never crimped or damaged by sharp edges. Never let the power-cord come into contact with other cables. Only handle the power-cord by the plug.

In case to replace the fuse, it must be changed by identical rate and dimensions.

Attention

Before connecting or operating your new loudspeaker, please study the accompanying instruction manual paying special attention to the operating precautions and wiring procedure.

BACK PANEL

Functions

1. USB /SD Player

MODE	USB / SD /Bluetooth 선택
▶II	Play/Pause
⟲	Repeat
⏮	Last
⏭	Next

2. MIC 1 LEVEL : Mic1 볼륨 조정

3. MIC 2 LEVEL : Mic2 볼륨 조정

4. LINE LEVER : Line 입력 볼륨 조정

5. TREBLE: -12dB to + 12dB 조정

6. 55 마이크 입력잭

7.MIC1 INPUT: XLR 마이크 입력잭

8. 55 마이크 입력잭

9. MIC 2 INPUT: XLR 마이크 입력잭

10.AUX IN : 3.5mm 입력잭

11. RCA 입력잭

12.LINE INPUT: Signal 입력잭

13.BASS: -12dB to + 12dB 조정

14.MP3 VOLUME : MP3 볼륨 조정

15.CLIP LED : 클릭에 불이 들어 올 경우는, 입력 레벨을 줄이세요

16.LINE OUTPUT: Signal 출력잭

17.POWER SWITCH : 전원스위치

18.MAIN SUPPLY INLET : 전원케이블 연결

EWD Corporation
본사 : 서울시 동대문구 전농동 113-70
전화 : 02-2245-7457 팩스 : 02-2246-7457

공장 및 A/S : 인천광역시 서구 석남2동 223-38 인천테크피아 가동 502호 동서테크
전화 : 032-584-0861 팩스 : 032-584-0862